Stainless Steel Electrodes (MMAW) SME 2209-16















SME 2209-16

Stick Electrodes (MMAW)

Stainless Steel

Classifications:

AWS A/SFA 5.4 : E 2209-16 IS 5206 : E 22.93 L R23

Coating Type : Rutile
Coating Factor : Medium
Identification : Brand Printed

Characteristics:

SME 2209-16 is used to weld duplex stainless steels such as (Type 2205). The welds offer good resistance to stress corrosion, cracking and pitting. Weld metal deposited by these electrodes has "duplex" microstructure consisting of an austenite-ferrite matrix.



Weld metal deposited by this electrodes combines increased tensile strength with improved resistance to pitting corrosive attack and to stress corrosion cracking. The slag is easily controlled and does not interfere with the arc action. Weld beads are smooth, and of good appearance.

Applications:

- 1) Welding of Duplex Austenitic-Ferritic stainless steel (UNS 31803) and cladding of Duplex Stainless Steel
- 2) Oil and Gas Industry
- 3) Off-shore platforms.
- 4) Chemical Industry

Mechanical Properties – All-Weld:

| Condition | UTS MPa | % Elong (L=4Xd) |
|-----------|---------|-----------------|
| As Welded | 760 | 25 |

Weld Metal Chemistry (wt%):

| С | Mn | Si | Mo | N | Ni | Cr | S+P |
|------|------|------|------|------|------|-------|------------|
| 0.03 | 1.00 | 0.83 | 3.00 | 0.15 | 8.50 | 22.00 | 0.030% max |

Current Conditions: AC, DC (+):

| 4.0 | 3.2 | 2.5 |
|--------|-------|-------|
| 90-125 | 70-90 | 50-70 |

Welding Positions:

F, H, V-up, OH

Re-drying Conditions:

To obtain best results re dry the electrodes at 300°C for 1hour (Optionally available in vacuum-packed condition, re-drying not required in this packaging).

SENOR

Note On Usage:

- 1) Keep electrode dry (Optionally also available in vacuum-packed condition, redrying not required in this packaging)
- 2) To obtain best results rebake the electrodes at $250 \sim 300$ °C for 1 hour and keep it at $100 \sim 150$ °C prior to use.
- 3) Use stainless steel wire brush for cleaning of slags
- 4) Follow the recommended welding parameters to achieve good sound welds
- 5) Do not use excessive currents. Hold short arc. Use good fit-up on joints.

Above are basic guidelines and will vary depending on joint design, number of passes and other factors.



Protect yourself and others. Read and understand this warning. Do not remove this warning.

Fumes and Gases can be hazardous to your health

- Before use, read and understand the Material Safety Data Sheet (MSDS), the manufacturer's instructions, and your employer's safety practices.
- If MSDS is not enclosed. Obtain from your employer.
- Keep your head out of the fumes. See Section 5 of the MSDS for specific fume concentration limits.
- Use enough Ventilation, exhaust at the arc, or both, to keep fumes and gases from your breathing zone and the general area. If needed, use a proper respirator.
- No hazards exist before this product is used in arc welding.

Electric Shock can kill

- Always wear dry insulating gloves
- Insulate yourself from work and ground.
- Do not touch live electrical parts.

ARC Rays can injure eyes and burn skin

- Wear welding helmet with correct filter.
- Wear correct eye, ear, and body protection.

Welding can cause fire or explosion

- Do not weld near flammable material.
- Watch for fire, keep, extinguisher nearby.

Read American National Standards Z49.1, "Safety In Welding, Cutting and Allied Process." from American Welding Society.